

READ THIS!

**Follow instructions inside this card
for connecting copper tubing
to the float valve.**

**Disregard all other float valve
plumbing instructions included
with the humidifier.**



Part No. 000-0756-258
HBP 12/17

Part No. 000-0756-258
HBP 12/17



**Follow instructions inside this card
for connecting copper tubing
to the float valve.
Disregard all other float valve
plumbing instructions included
with the humidifier.**

READ THIS!